



# I. INTRODUCTION

SAFETY






























WARNING! Pride strongly recommends that you do not smoke cigarettes while seated in your  
Go-Chair, Nerd
























/





## VI. BATTERIES AND CHARGING

### BATTERIES AND CHARGING

The Go-Chair uses two long-lasting, 12-volt, deep-cycle batteries. These batteries are sealed and maintenance free. Since they are sealed, there is no need to check the

















## **Storage**


Your Go-Chair should be stored in a dry place, free from temperature extremes. When storing, disconnect the batteries from the Go-Chair. See VI. “Batteries and Charging.”

WARNING! If you fail to store






# VIII. WARRANTY







**Figure 26. Go-Chair Dimensions and Ground Clearance**





