











PROHIBITED! Removal of grounding prong can create electrical hazard. If necessary,



V. OPERATION

BEFORE GETTING ON YOUR SCOOTER

- › Have you fully charged the batteries? See IV. “Batteries and Charging.”
- ›

VI. COMFORT ADJUSTMENTS





NYLON LOCK NUT REPLACEMENT

Any nylon insert lock nut removed during the periodic maintenance, assembly, or disassembly of the scooter must be replaced with a new nut. Nylon insert lock nuts should not be reused as it may cause damage to the nylon insert, resulting in a less secure fit. Replacement nylon insert lock nuts are available

NOTES

